TonUINO Konfiguration

HW	Arduino Nano V3; RFID-RC522; DF-Player Chip MH2024K24SS
SW	TonUINO-TNG_Issue188
Defines	TonUINO_Classic; FIVEBUTTONS; DFMiniMp3_T_CHIP_LISP3 mit Änderung "dfPlayer_timeUntilStarts = 3600" in constants.hpp, Zeile 341
Einstellungen (Admin)	**Pause, wenn Karte entfernt wird = NEIN**

Karte	Aktion / Status	erwartet	Ergebnis	OK
	Einschalten + Booten	play mp3 262	play mp3 262	X
	Card inserted - single X	play X	play X	X
	press pause	enter pause	enter pause	X
	press pause	enter play X	enter play X	X
	long press pause	play adv: X + enter play X	play adv: X + enter play X	X
	long press pause	play adv: X + enter play X	play adv: X + enter play X	X
	press pause	enter pause	enter pause	X
	long press pause	nothing or enter play X	play mp3 262 + shutdown	?
	Card inserted - party	play Y	play Y	X
	press pause	enter pause	enter pause	X
	press pause	enter play Y	enter play Y	X
	long press pause	play adv: Y + enter play Y	play adv: Y + enter play Y	X
	long press pause	play adv: Y + enter play Y	play adv: Y + enter play Y	X
	press pause	enter pause	enter pause	X
	long press pause	nothing or enter play Y	play mp3 262 + shutdown	?
	Card inserted - hörspiel	play Z	play Z	X
	press pause	enter pause	enter pause	X
	press pause	enter play Z	enter play Z	X
	long press pause	play adv: Z + enter play Z	play adv: Z + enter play Z	X
	long press pause	play adv: Z + enter play Z	play adv: Z + enter play Z	X
	press pause	enter pause	enter pause	X
	long press pause	nothing or enter play Z	play mp3 262 + shutdown	?

TonUINO Konfiguration

HW	Arduino Nano V3; RFID-RC522; DF-Player Chip MH2024K24SS
SW	TonUINO-TNG_Issue188
Defines	TonUINO_Classic; FIVEBUTTONS; DFMiniMp3_T_CHIP_LISP3 mit Änderung "dfPlayer_timeUntilStarts = 3600" in constants.hpp, Zeile 341
Einstellungen (Admin)	**Pause, wenn Karte entfernt wird = JA**

Karte	Aktion / Status	erwartet	Ergebnis	OK
	Einschalten + Booten	play mp3 262	play mp3 262	X
	Card inserted X (single)	play X (from start)	play X (from start)	X
	press pause	enter pause	enter pause	X
	press pause	enter play X (continue)	enter play X (continue)	X
	Card Removed	enter pause	enter pause	x
	press pause	nothing	nothing	X
	Card inserted X (single)	play X (continue)	play X (continue)	x
	press next	nothing	nothing	X
	press previous	play X (from start)	play X (from start)	x
	Card Removed	enter pause	enter pause	X
	Card inserted Y (single)	play Y (from start)	play Y (from start)	x
	Card Removed	enter pause	enter pause	X
	Card inserted Y (single)	play Y (continue)	play Y (continue)	x
	long press pause	play adv: Y + enter play Y (cont.)	play adv: Y + enter play Y (cont.)	
	Card Removed	enter pause	enter pause	X
	long press pause	??	play mp3 262 + shutdown	?
	Card inserted P (party)	play P (from start)	play P (from start)	X
	press pause	enter pause	enter pause	x
	press pause	enter play P (continue)	enter play P (continue)	X
	press pause	enter pause	enter pause	x
	Card Removed	nothing	nothing	X
	Card inserted P (single)	play P (continue)	play P (continue)	x
	press next	play P+1 (from start)	play P+1 (from start)	X
	press previous	play P (from start)	play P (from start)	x
	press previous	play P-1 (from start)	play P-1 (from start)	X
	Card Removed	enter pause	enter pause	x
	press pause	nothing	nothing	X
	long press pause	??	play mp3 262 + shutdown	?
	Card inserted P (party)	play P-1 (continue)	play P-1 (continue)	x
	long press pause	play adv: P-1 + enter play P-1 (cont.)	play adv: P-1 + enter play P-1 (cont.)	X
	Card inserted H (Hörspiel)	play H (from start)	play H (from start)	X
	press pause	enter pause	enter pause	x
	press pause	enter play H (continue)	enter play H (continue)	X
	Card Removed	enter pause	enter pause	x
	press pause	nothing	nothing	X
	Card inserted H (Hörspiel)	play H (continue)	play H (continue)	x
	long press pause	play adv: H + enter play H (cont.)	play adv: P-1 + enter play P-1 (cont.)	X
	Card Removed	enter pause	enter pause	x
	long press pause	enter idle		V
	long press pause	play mp3 262 + shutdown		V
	Card inserted H (Hörspiel)	play H+x (from start)	play H+x (from start)	X
	Card Removed	enter pause	enter pause	x
	Card inserted H (Hörspiel)	enter play H+x (continue)	enter play H+x (continue)	X